



**TENANT SMOKE CONTROL SCHEMATIC**

**Smoke Zone Sequence**

1. Tenant zone in fire mode: 100% smoke exhaust; 0% supply air
2. Remaining Tenant zones: Normal HVAC system operation
3. Adjacent mall zones: 100% outside air supply; 0% return or exhaust air
4. Remaining mall zones: Normal HVAC system operation

**Notes**

1. Smoke control sequencing/shut down shall be via the Building Management System (BMS), in response to inputs from fire alarm control system. The smoke control system shall be automatic with "H-O-A" manual override capability.
2. Tenants are responsible to fit out ductwork, air terminals, ceilings, etc. in Tenant spaces (typical).